



## **GENERAL NOTES:**

-PL PREMIUM ADHESIVE MUST BE USED ON ALL BEDDING/BUTT JOINTS

## SPECTIS MOULDERS INC.

TO SET THANK FRENCE

P.O. BOX 970 100 CEDAR DRIVE NIVERVILLE, MANITOBA CANADA ROA 1E0 PHONE: 204-388-6700 PHONE: 800-685-9981 FAX: 204-388-6710 BOX 479 PEMBINA, NORTH DAKOTA 58271-0479 U.S.A

GENERAL NOTES:

1. ALL PRODUCTS ARE DRAWN FOR PRESENTATION PURPOSSES, ONLY IMAGE MAY VARY SLIGHTLY FROM ACTURAL PART

2. DRAWING INTENT IS TO INDICATE GENERAL ARRANGEMENT, DESIGN AND INTENT OF WORK IS PARTLY DIAGRAMATIC.

2. DRAWING INTENT IS TO INDICATE GENERAL ARRANGEMENT, DESIGN AND INTENT OF WORK IS PARTLY DIAGRAMATIC.

3. SPECTIS RESERVES THE RIGHT TO CHANGE ANY PRODUCT DESIGN WITHOUT

CUSTOMER NAME:			PART:
STANDARD PRODUCT			MD 1716
REFERENCE:			SHEET:
MOULDING			
DRAWN BY:	DATE:	SCALE:	REV:
JE	06/12/15	3/4 = 1"	