



## **GENERAL NOTES:**

-BACKSIDE OF MOULDING TO BE HOLLOW -PL PREMIUM ADHESIVE MUST BE USED ON ALL BEDDING/BUTT JOINTS

## SPECTIS MOULDERS INC.



P.O. BOX 970 100 CEDAR DRIVE NIVERVILLE, MANITOBA CANADA ROA 1E0

PHONE: 204-388-6700 PHONE: 800-685-9981 FAX: 204-388-6710

PEMBINA, NORTH DAKOTA 58271-0479 U.S.A

GENERAL NOTES:

1. ALL PRODUCTS ARE DRAWN FOR PRESENTATION PURPOSSES, ONLY IMAGE MAY VARY SLIGHTLY FROM ACTURAL PART

2. DRAWING INTENT IS TO INDICATE GENERAL ARRANGEMENT, DESIGN AND

© 2006, Specis Moulders Inc. All rights
3. SPECTIS RESERVES THE RIGHT TO CHANGE ANY PRODUCT DESIGN WITHOUT reserved. This document may not be used or duplicate without prior consent.

CUSTOMER NAME:			PART:
STANDARD PRODUCT			MD 1731
REFERENCE:			SHEET:
DRAWN BY:	DATE:	SCALE:	REV:
JE	07/01/25	<sup>3</sup> / <sub>16</sub> = 1"	